

**SOLID WOOD PRE FINISHED WORKTOP**  
**RECEIPT, STORAGE & INSTALLATION GUIDE**  
**IMPORTANT PLEASE READ !**

**Installer & Owner Responsibilities**

All worktops are supplied pre finished. (see "Finishing Instructions"). Upon unwrapping it is important to inspect the worktop carefully for any damage or defects of any kind. As wood is a natural material its colour and shade will vary so ensure your worktop/s are visually acceptable in all respects before installation. Any defects found must be reported to your supplier immediately and resolved before proceeding. The quality of the oiling & fitting of the product has a major impact on the overall look and performance of your chosen worktop therefore it is important to ensure you or your chosen installer is suitably experienced with regard to hardwood worktop installation.

Before commencing the installation of your worktops you, and or, your installer should read and fully understand these instructions. If in doubt please contact your supplier for advice before you undertake any work on the worktop. **Failure to adhere to these instructions will invalidate the associated product warranty.** (A copy of your product warranty is available via your worktop supplier)

**STORAGE.**

Wood is a natural material and can be affected by unsuitable and varying temperature and humidity. Worktops MUST be stored flat and be fully supported along their length at all times and be kept in their original packaging and away from a direct heat source, i.e. a radiator. **Never store vertically or on edge**, as this will induce bowing.

The worktops must be stored in a dry environment with room atmospheric conditions being 35 – 55% Relative Humidity and temperature range of 16 – 24 deg C.

**IMPORTANT: The worktop is supplied pre finished and can be installed without prior oiling except that all exposed cut edges must be sufficiently oiled prior to fitting (see finishing information). The importance of correct and sufficient oiling cannot be overstated.**

**INSTALLATION**

To assist with a trouble free installation and ensure you have all the correct accessories required to do so a **Hardwood Worktop Installation Kit** is available from your worktop supplier.

- A. IMPORTANT.** Prior to installation you must oil all exposed cut edges with a minimum of five coats, paying particular attention to end grains. Upstands must also be oiled using the same procedures where cut edges have occurred. (See "Finishing instructions" re tinting and oil application) Follow drying times specified between coats in the "Finishing instructions" below)
- B.** Allow a 4 mm gap between the back edge of the worktop and the wall as this will allow the worktop to expand and contract within the humidity of the kitchen. We advise that an upstand is used to cover the gap. Fix the upstand to the wall and not the worktop. A flexible silicone seal should be used between the upstand and the worktop.
- C.** No cut outs for sinks, hobs, etc., should be nearer than 100 mm from the end of the worktop or between cut outs, as this will seriously weaken the worktop.
- D.** When a worktop is to be fitted near to a constant heat source, i.e. an AGA or Rayburn, allow a minimum gap of 40 mm between the ends of the worktop and the heat source unit. A solid wood return piece should be fixed across the end grain section of the worktop end, whilst retaining the 40mm clear space, to help prevent any splits occurring. **It is not recommended to install the worktop above a boiler.**
- E.** If a kitchen appliance (dishwasher, washing machine, refrigerator, etc...) is to be installed under the worktop, cover the exposed underside of the worktop above the appliance with a sheet of moisture barrier building paper using PVA wood glue to adhere it to the underside of the worktop. This will help to protect the worktop from any intense heat or moisture that radiates from these types of appliances, particularly dishwashers. Use the same procedure for installations when you are fixing to brickwork. The foil faced paper is provided within the **Hardwood Worktop Installation Kit** is available from your worktop supplier.
- F.** If drainer grooves are to be cut into the worktop surface then extra care must be taken to ensure that the grooves are machined as central as possible within the individual stave blocks and not machined along the glued joints between the stave blocks. **Note:** As there is a potential for water to sit in the grooves, it is essential that the grooves and surrounding areas are oiled correctly following the guidelines within this installation guide to avoid splitting and discolouration. (We would recommend that a drip tray / rack is used when draining dishes). Should any issues arise due to incorrectly positioned, poorly machined or incorrectly sealed, drainer grooves being cut into the worktop then the associated product warranty is void. (see additional comments re "when applying coloured oil in machined draining grooves")
- G.** If a carcass has a solid top or you can only secure through the cross-rail it is important to drill an oversized hole (8-10mm) through the top of the carcass and secure to the worktop using a larger flat washer and screw. This will allow the work surface to slide over the washer in case of any possible expansion or contraction of the worktops in situ. **(Do not screw through the carcass directly into the worktop without oversize holes).**
- H.** It is important that 3 slotted angle brackets are used across the width at regular intervals along the length of the worktop, especially at the end of a worktop run.
- I.** When joining two worktops together three standard worktop bolts must be used on each joint. The additional use of biscuit joints is also recommended.
- J.** All joints **should be Butt jointed** and not Mitred. A short Mason Mitre can be used for profiled edges.
- K.** It is **not recommended that a solid wood worktop be installed without supporting cabinets**, i.e. a peninsular breakfast bar with support leg. If this is to be used an adequate cross bracing framework must be used supporting the full underside of the worktop.
- L.** When installing a Butler/Belfast sink **it is essential to apply additional coats of oil** to the underside and edges before installation as this area will be subject to continual splashes and will be inaccessible once installed. **A continuous waterproof silicone seal must be installed between the top of the sink and the underside of the worktop to prevent water ingress.** A drip groove should also be installed on the underside around the edge over the sink.

# **FINISHING YOUR WORKTOP AND AFTERCARE TO MAINTAIN YOUR WORKTOPS**

## **PLEASE ENSURE YOUR CUSTOMER READS AND RETAINS THIS DOCUMENT**

Please ensure our installation and maintenance kit is used to treat the worktop. The combination of the pre finished worktop and the subsequent oiling will penetrate into the wood to form a hard, durable and water resistant finish to the worktop, however the finish is not ultimately waterproof long term and therefore regular re oiling of your worktop as necessary is required (see the "Maintenance / Aftercare of your worktops" section as below).

### **FINISHING INSTRUCTIONS/COMBINED WITH THE INSTALLATION KIT**

**Preparation** – Any exposed timber surfaces resulting from cutting must be dry, clean and free of dust.

#### **Part one**

**Coloured wood oils** are ready to use straight from the tin, please do not thin but stir thoroughly before use.

The tinted oil is to be applied to areas that have exposed the raw wood due to cut ends/sink cut outs etc

Please ensure these areas are sanded and free of dust before applying the tinted oil.

Apply thinly with the brush provided. Allow 24 hours to dry, ensuring good ventilation. (Normal climatic conditions apply 23°C/50% rel. humidity. Lower temperatures and higher humidity can increase drying time.)

If a more intense colour tone is required apply a second coat.

Cleaning of brush: White spirit

Care must also be taken to ensure that when a coloured oil is used to seal drainer grooves, it is applied in thin coats allowing the correct drying time to ensure that a comparable colour tone to the rest of the worktop is achieved. Applying too much oil per coat may result in a darker colour finish occurring within the drainer grooves.

Inside your installation kit we have provided a polishing pad which has been designed to increase the sheen level when using the white side and reduce the sheen when using the green side. This can be used to ensure a matching sheen.

#### **Part two**

**Top Oil** – Top oil is a professional, clear, satin-matt finish based on natural vegetable oils and waxes.

Top Oil is ready to use straight from the tin. Please do not thin but stir thoroughly before use.

Your worktop has been delivered pre oiled and does not require immediate re oiling after installation except where any light surface scuffs or scratches occur during installation in which case a final full coat of oil should be applied.

**Important:** All cut ends/sink cut outs/drainers grooves etc will require a minimum of four coats of top oil in addition to the coloured base coat as in part one.

Apply the coats thinly with a cloth wiping off any excess after 5 minutes. Leave to dry overnight (at least 8–10 hours) ensuring good ventilation. (Normal climatic conditions apply 23°C/50% rel. humidity. Lower temperatures and higher humidity can increase drying time.)

Please pay particular attention to the SINK AREAS.

### **MAINTENANCE / AFTERCARE OF YOUR WORKTOPS**

Please remember that wood is a natural material and an appropriate on going regime of oil treatment is essential to maintain the factory pre finished surface protection against stains and humidity, which will ensure a long and trouble free life.

Inside your installation kit we have provided a polishing pad which has been designed to increase the sheen level when using the white side and reduce the sheen when using the green side. This is to be used if making a maintenance repair to ensure a matching contrast.

If you need to restore the sheen of the tops in the future when you feel they start to look a little dull, or for precaution every 6 months, a further coat of Top Oil will return them to their natural beauty. The surfaces can be cleaned with damp cloth containing a small amount of dishwashing agent.

### **Oils - CAUTION**

**Keep all oils out of reach of Children**

**Wear appropriate personal protection equipment as recommended by the oil manufacturer within the product instructions.**

**Ensure good ventilation within the room when applying oils - In case of contact with eyes rinse immediately with water**

### **IMPORTANT – Do's & Don'ts and things to Avoid!**

**Do:** **Do ensure your worktops are checked upon receipt of them:** Claims for damage or shortages etc. cannot be accepted if they are not notified of to your supplier within 72 hours of receiving the goods.

**Do ensure your worktops are correctly stored flat and in a suitably dry environment:** Claims for issues relating to inappropriate storage and the effects of unsuitable humidity of moisture affecting your worktops cannot be accepted by the manufacturer and will invalidate your product warranty.

**Do ensure that your chosen installer is appropriately competent and experienced:** With solid wood worktop installation, any issues or complaint relating to incorrect installation techniques or practices will invalidate your product warranty.

**Do ensure you, and or, your installer reads these installation instructions:** As then any queries can be raised and clarified prior to the installation taking place and installation errors avoided.

**Do ensure that any cut edges of the worktops are correctly finished with the Top oil provided in the installation kit:** Applying the oil and stated amount of coats on the exposed and cut edges is vital to the early protection of the worktops and ongoing longer term protection for these cut edge points.

**Don't:** **Don't store your worktops vertically or on edge:** They must be laid flat and be fully supported along their length.

**Don't place any objects on the surface of your worktops whilst in storage:** Damage and scratching of the worktops can occur.

**Don't install your worktops if you have doubts as to the competence of your, or your installers, skills and abilities:** It is always prudent to have an experienced installer to install your worktops.

**Don't place hot pans on the surface of your worktop:** As the surface of it can be damaged and discoloured.

**Avoid:** **Avoid scratching your solid worktop:** By using an appropriate chopping block for cutting and preparing foods etc.

**Avoid staining your worktop:** Ensure that the initial recommended coats of oil are applied prior to, and following, installation of your worktops and appropriate coats of oil are applied as necessary ongoing from a maintenance perspective.

#### **Disclaimer**

Wood is a natural product and so the colour and grain may vary. The work surfaces are manufactured from selected materials and are subject to quality control procedures. These work surfaces may contain knots, natural colour variations and drying shakes as normal features of the product.

Edition 2 COL/UV - March 2017